

# LED Status

Note for users: If you see any states besides Solid GREEN or Blinking GREEN, please contact Machine Saver technical support for troubleshooting assistance.

| LED State                          | Description                                  |
|------------------------------------|--|
| Solid <b>GREEN</b>                 | All subsystems are good, no vibration alarms |
| Blinking <b>GREEN</b>              | Vibration Alarms                             |
| Solid <b>RED</b>                   | Internal Hardware Error                      |
| Alternating <b>2RED, 2GREEN</b>    | Bootloader Mode                              |
| Alternating<br><b>1RED, 1GREEN</b> | Bootloader Mode (Older Version )             |
| Alternating<br><b>3RED, 1GREEN</b> | Calibration Issue                            |

Revision #2

Created 22 March 2022 17:10:55 by Bach\_L

Updated 23 June 2022 06:48:09 by Bach\_L